

CALIBRATION CHART
TANK DIA. 67"

T-625

=====

<u>po</u>	<u>USG</u>	<u>po</u>	<u>USG</u>
1	22	34	3673
2	63	35	3810
3	114	36	3947
4	175	37	4084
5	244	38	4220
6	319	39	4355
7	400	40	4490
8	487	41	4624
9	578	42	4757
10	673	43	4889
11	773	44	5020
12	876	45	5149
13	983	46	5277
14	1093	47	5403
15	1206	48	5528
16	1321	49	5650
17	1439	50	5771
18	1560	51	5889
19	1682	52	6004
20	1807	53	6117
21	1933	54	6227
22	2061	55	6334
23	2190	56	6437
24	2321	57	6537
25	2453	58	6632
26	2586	59	6723
27	2720	60	6810
28	2853	61	6891
29	2990	62	6966
30	3126	63	7034
31	3263	64	7095
32	3399	65	7147
33	3536	66	7188
34	3673	67	7210